

User Manual

BGM1000 Series Barrier Gate (APP Version)

Date: March 2024

Doc Version: 1.3

English

Thank you for choosing our product. Please read the instructions carefully before operation. Follow these instructions to ensure that the product is functioning properly. The images shown in this manual are for illustrative purposes only.



For further details, please visit our Company's website
www.zkteco.in.

Copyright © 2024 ZKTECO CO., LTD. All rights reserved.

Without the prior written consent of ZKTeco, no portion of this manual can be copied or forwarded in any way or form. All parts of this manual belong to ZKTeco and its subsidiaries (hereinafter the "Company" or "ZKTeco").

Trademark

ZKTeco is a registered trademark of ZKTeco. Other trademarks involved in this manual are owned by their respective owners.

Disclaimer

This manual contains information on the operation and maintenance of the ZKTeco equipment. The copyright in all the documents, drawings, etc. in relation to the ZKTeco supplied equipment vests in and is the property of ZKTeco. The contents hereof should not be used or shared by the receiver with any third party without the express written permission of ZKTeco.

The contents of this manual must be read as a whole before starting the operation and maintenance of the supplied equipment. If any of the content(s) of the manual seems unclear or incomplete, please contact ZKTeco before starting the operation and maintenance of the said equipment.

It is an essential pre-requisite for the satisfactory operation and maintenance that the operating and maintenance personnel are fully familiar with the design and that the said personnel have received thorough training in operating and maintaining the machine/unit/equipment. It is further essential for the safe operation of the machine/unit/equipment that personnel has read, understood and followed the safety instructions contained in the manual.

In case of any conflict between terms and conditions of this manual and the contract specifications, drawings, instruction sheets or any other contract-related documents, the contract conditions/documents shall prevail. The contract specific conditions/documents shall apply in priority.

ZKTeco offers no warranty, guarantee or representation regarding the completeness of any information contained in this manual or any of the amendments made thereto. ZKTeco does not extend the warranty of any kind, including, without limitation, any warranty of design, merchantability or fitness for a particular purpose.

ZKTeco does not assume responsibility for any errors or omissions in the information or documents which are referenced by or linked to this manual. The entire risk as to the results and performance obtained from using the information is assumed by the user.

ZKTeco in no event shall be liable to the user or any third party for any incidental, consequential, indirect, special, or exemplary damages, including, without limitation, loss of business, loss of profits, business interruption, loss of business information or any pecuniary loss, arising out of, in connection with, or relating to the use of the information contained in or referenced by this manual, even if ZKTeco has been advised of the possibility of such damages.

This manual and the information contained therein may include technical, other inaccuracies or typographical errors. ZKTeco periodically changes the information herein which will be incorporated into new additions/amendments to the manual. ZKTeco reserves the right to add, delete, amend or modify the information contained in the manual from time to time in the form of circulars, letters, notes, etc. for better operation and safety of the machine/unit/equipment. The said additions or amendments are meant for improvement /better operations of the machine/unit/equipment and such amendments shall not give any right to claim any compensation or damages under any circumstances.

ZKTeco shall in no way be responsible (i) in case the machine/unit/equipment malfunctions due to any non-compliance of the instructions contained in this manual (ii) in case of operation of the machine/unit/equipment beyond the rate limits (iii) in case of operation of the machine and equipment in conditions different from the prescribed conditions of the manual.

The product will be updated from time to time without prior notice. The latest operation procedures and relevant documents are available on <http://www.zkteco.in>.

If there is any issue related to the product, please contact us.

ZKTeco Biometrics India Pvt Ltd.

Address B-1, Khata No. 31, Devasandra Industrial Estate,
Whitefield Main Road, Beside Phoenix mall,
Mahadevapura, Bengaluru-560048, Karnataka, India.

Phone 080 6828 1342

For business-related queries, please write to us at sales@zkteco.in.

To know more about our global branches, visit www.zkteco.com.

About the Company

ZKTeco is one of the world's largest manufacturer of RFID and Biometric (Fingerprint, Facial, Finger-vein) readers. Product offerings include Access Control readers and panels, Near & Far-range Facial Recognition Cameras, Elevator/floor access controllers, Turnstiles, License Plate Recognition (LPR) gate controllers and Consumer products including battery-operated fingerprint and face-reader Door Locks. Our security solutions are multi-lingual and localized in over 18 different languages. At the ZKTeco state-of-the-art 700,000 square foot ISO9001-certified manufacturing facility, we control manufacturing, product design, component assembly, and logistics/shipping, all under one roof.

The founders of ZKTeco have been determined for independent research and development of biometric verification procedures and the productization of biometric verification SDK, which was initially widely applied in PC security and identity authentication fields. With the continuous enhancement of the development and plenty of market applications, the team has gradually constructed an identity authentication ecosystem and smart security ecosystem, which are based on biometric verification techniques. With years of experience in the industrialization of biometric verifications, ZKTeco was officially established in 2007 and now has been one of the globally leading enterprises in the biometric verification industry owning various patents and being selected as the National High-tech Enterprise for 6 consecutive years. Its products are protected by intellectual property rights.

About the Manual

This manual introduces the operations of BGM1000 Series Barrier Gate (APP Version).

All figures displayed are for illustration purposes only. Figures in this manual may not be exactly consistent with the actual products.

Document Conventions

Conventions used in this manual are listed below:

GUI Conventions

For Software	
Convention	Description
Bold font	Used to identify software interface names e.g., OK , Confirm , Cancel .
>	Multi-level menus are separated by these brackets. For example, File > Create > Folder.
For Device	
Convention	Description
< >	Button or key names for devices. For example, press <OK>.
[]	Window names, menu items, data table, and field names are inside square brackets. For example, pop up the [New User] window.
/	Multi-level menus are separated by forwarding slashes. For example, [File/Create/Folder].

Symbols






Convention	Description
	This represents a note that needs to pay more attention to.
	The general information which helps in performing the operations faster.
	The information which is significant.
	Care taken to avoid danger or mistakes.
	The statement or event that warns of something or that serves as a cautionary example.

Table of Contents

1	OVERVIEW.....	7
2	FEATURES AND FUNCTIONALITIES	7
3	APPEARANCE AND DIMENSIONS	8
4	SPECIFICATIONS	8
5	INSTALLATION PROCEDURE.....	9
5.1	INSTALLATION PRECAUTIONS	9
5.2	CABLE EMBEDDING	9
5.3	BOOM ARM INSTALLATION	10
5.3.1	BOOM ARM INSTALLATION PROCEDURE.....	10
6	LEFT AND RIGHT DIRECTIONS	11
7	MAINBOARD WIRING INSTRUCTIONS	11
7.1	WIRE CONNECTION OF THE NEW MAINBOARD	12
7.2	CONNECTION WITH LPR CAMERA	12
7.3	CONNECTION WITH UHF CONTROLLER	13
7.4	CONNECTION WITH LOOP DETECTOR	13
7.5	CONNECTION WITH VR10 RADAR SENSOR.....	14
7.6	CONNECTION WITH INFRARED/PHOTOCELL DETECTOR.....	15
8	FUNCTIONAL PARAMETER SETTINGS	16
8.1	MAINBOARD PARAMETER SETTINGS	16
8.1.1	OPERATING PROCEDURE	17
8.2	PARAMETER SETTINGS DESCRIPTION	17
8.3	ERROR CODE.....	24
8.4	REMOTE CONTROL PAIRING AND UNPAIRING	25
8.4.1	PAIRING.....	25
8.4.2	UNPAIRING.....	25
8.5	SET DELAY FOR AUTOMATIC CLOSING AFTER OPENING THE BOOM ARM.....	25
9	BOOM ARM ADJUSTMENTS	26
9.1	DIMENSIONS	26
9.2	HORIZONTAL AND VERTICAL ANGLE ADJUSTMENT OF BOOM ARM (MECHANICAL ADJUSTMENT) 26	
9.3	DIRECTION INTERCHANGE OF THE BOOM ARM	28

9.4 SPRING ADJUSTMENT 29

10 PRODUCT PACKING LIST 29

11 TROUBLESHOOTING 30

12 SAFETY PRECAUTIONS 31

13 TRANSPORTATION AND STORAGE..... 31

14 WARRANTY..... 31

1 Overview


BGM1000 series barrier gate is a high-performance barrier gate that adopts ZKTeco's interactive LED chassis design. It controls the flow of the traffic in and out of the premises providing maximum security at a low cost. It adopts ARM7 embedded system control core, brushless DC motor, and SCM421 material gear transmission structure to offer maximum efficiency.

It has the advantages of high speed, efficiency, stable quality, user-friendly customization, comprehensive performance, and so on. It can be used in real-time application areas such as offices, hospitals, public places, residential areas to ease traffic issues.

2 Features and Functionalities

- The operating speed is 1.5s, and the speed can be adjusted according to different boom arm lengths.
- Reversible left and right directions.
- The transmission mechanism is simple, compact, and easy to install on-site.
- Interactive and stylish chassis LED design.
- Equipped with digital control monitoring, thus supports delay in automatic close, automatic test, rise/fall output status display.
- Supports automatic power-off, manual rise of the boom arm, anti-smash, and fire linkage functions.
- The angle of rise/fall of the arm can be adjusted, and the digital encoder is adopted to limit the position automatically, thus replacing the traditional limiting procedure. The position control is accurate.
- 24V backup battery can be used to ensure the normal operation of the barrier when power is off.
- The chassis is made of a 2.0mm metal sheet through an electrophoretic and powder spraying process.
- The boom will bounce back when it is blocked.

3 Appearance and Dimensions



4 Specifications

Model	BGM1030 L/R	BGM1045 L/R	BGM1060 L/R	BGM1045 L/R-LED	BGM1145 L/R-90
Operating Speed	1.5s	2.5s	5s	2.5s	2.5s
Boom Arm Length	3m	4.5m	6m	4.5m	4.5m
Boom Arm Type	Straight boom	Telescopic boom		Straight boom with LED	Folding boom
Chassis Dimension (W*L*H)	350*300*1020 (mm)				
Motor Type	DC 24V brushless motor				
Output Power	120W				
Rated Current	6A				
Power Supply	AC 220V, 50Hz / AC 110V, 60Hz				
Operating Temperature	-35°C to 70°C				
Operating Humidity	<90%				
Motor MCBF	3 million times				
Remote Control Distance	≤30m				
Chassis Weight	45kg				


5 Installation Procedure

5.1 Installation Precautions

1. Install the parking barrier on a flattened ground. A cement foundation is required before installation if the ground is not solid and flat.
2. It is possible to reduce the length of the boom arm, but it cannot be increased. After the boom arm has been cut, it is important to set the spring balance again to achieve a new balance. The bottom of the spring contains two plastic nuts designed to adjust the new balance.
3. When powered on, do not change the wire connection inside.
4. Connect the GND to the cabinet for ensured protection.

5.2 Cable Embedding

1. A $\phi 25$ protective sleeve and a cable are required.
2. The route cables must pass through the protective sleeves.
3. Use a tool to open the cable tray on the ground.



5.3 Boom Arm Installation

5.3.1 Boom Arm Installation Procedure

1. Separate the secondary boom arm from the upper boom arm and fasten it with two screws., as shown in Figure 1.
2. The procedure of installing the boom arm to the chassis is shown in Figure 2.



Figure 1 Connect the main boom arm with the Secondary arm together by 2 screws





Figure 2 Install the Boom Arm to the Chassis

Note:


- 1) Before the barrier is powered on to run the test process, be sure to install the barrier boom arm of the corresponding length for the test. If the barrier boom arm is not installed, please adjust and remove the spring under the guidance of a professional.
- 2) If the length of the barrier boom arm is cut and adjusted, the tightness of the spring and the position of the hanging hole need to be adjusted accordingly to avoid the abnormal working status that cannot drop the boom.

6 Left and Right Directions



7 Mainboard Wiring Instructions


1. Please disconnect the power supply before wiring.
2. To Please note that to change the input voltage, you must set the **DIP switch to 110V** as shown in the below image:




3. Check carefully whether the terminals are tightened and whether the wiring is firm.

7.1 Wire Connection of the New Mainboard

Wiring diagram of new control board of the app version:




7.2 Connection with LPR Camera




7.3 Connection with UHF Controller

(Note: The Reader1 and 2 of Inbio260 Controller corresponds to LOCK1, Reader3 and 4 corresponds to LOCK2)



7.4 Connection with Loop Detector


Anti-smash and Auto-close function



Coil Circumference	Coil Number
3m	Based on requirements, ensure that the inductance is between 100μH and 200μH
3m to 6m	5 to 6 turns
6m to 10m	4 to 5 turns
10m to 25m	3 turns
25m	2 turns


7.5 Connection with VR10 Radar Sensor

Anti-smash and Auto-close function





7.6 Connection with Infrared/Photocell Detector

Anti-smash function



Anti-smash and Auto-close function






8 Functional Parameter Settings

After the initial installation, and first power-on, you must use the "**Open**" and "**Close**" buttons on the mainboard to complete the self-check process and learn the description of the menu.

8.1 Mainboard Parameter Settings





Menu/Save: Menu options/Confirm and Save

Stop/▼: Stop the boom arm /button to switch the menu item and the value item

Open/+: Increase parameter/value

Close/-: Decrease parameter/value

8.1.1 Operating Procedure



8.2 Parameter Settings Description

Items	Description	Default
01E.***	Display Mode	01E.001
	• 01E.000: Displays current position of the boom arm	
	• 01E.001: Controls input signal (displays the status as "F*.***")	
	1F*.***: Opening position	
	2F*.***: Closing position	
	5F*.***: Opening	
	6F*.***: Closing	
	4F*.***: In the pause	
	0F*.***: Not self-tested	
	7F*.***: Not stop at the open/close limit	
	• 01E.002: Test mode	
	• 01E.003: Number of boom openings	
	• 01E.004: Version Information	

02E.***	<p><u>Boom Arm Opening Speed</u></p> <p>Set the Boom Arm Opening Speed to open the gate. The larger the number is set, the faster the speed. The Boom Arm Opening Speed value can be set between 10 to 32 and the default value is 24.</p>	02E.024
03E.***	<p><u>Boom Arm Opening Brake Stroke</u></p> <p>The larger the number, the greater the deceleration stroke.</p> <p>The deceleration stroke is too large, which may cause the boom arm to not open up to the limit.</p> <p>The Boom Arm Opening Brake Stroke can be set between 0 to 100 and the default value is 30.</p>	03E.030
04E.***	<p><u>Boom Arm Opening Brake Speed</u></p> <p>The smaller the number, the more pronounced the deceleration effect.</p> <p>If the deceleration speed is too small, it may cause the boom arm to not open up to limit, and the digital display will show: E*0.032.</p> <p>The Boom Arm Opening Brake Speed can be set between 0 to 100 and the default value is 10.</p>	04E.010
05E.***	<p><u>Boom Arm Closing Speed</u></p> <p>Set the Boom Arm Closing Speed to close the gate. The larger the number is set, the faster the speed. The Boom Arm Closing Speed value can be set between 10 to 32 and the default value is 20.</p>	05E.020
06E.***	<p><u>Boom Arm Closing Brake Stroke</u></p> <p>The larger the number, the greater the deceleration stroke.</p> <p>The deceleration stroke is too large, which may cause the boom arm to not close down to limit.</p> <p>The Boom Arm Closing Brake Stroke can be set between 0 to 100 and the default value is 40.</p>	06E.040

07E.***	<p><u>Boom Arm Closing Brake Speed</u></p> <p>The smaller the number, the more pronounced the deceleration effect.</p> <p>If the deceleration speed is too small, it may cause the boom arm to not close down to limit. If the boom doesn't close to limit, it will automatically bounce back to the open state (similar to rebounding when encountering resistance). If the ground sensing is triggered at this time, the barrier gate will continuously open and close.</p> <p>The Boom Arm Closing Brake Speed can be set between 0 to 100 and the default value is 10.</p>	07E.010
08E.***	<p><u>Sensitivity of the Boom Arm Bouncing</u></p> <p>Sets the bounce sensitivity of the boom arm when it encounters an obstacle. The higher the value, the lower the sensitivity, and the longer it will take to bounce. When set to 100, this function will be turned off and the boom arm will not bounce when it encounters an obstacle. It can be set between 20 and 100, the default value is 40.</p>	08E.040
09E.***	<p><u>Close Limit Adjustment</u></p> <p>It can be set between 0 to 60, the default value is 4.</p>	09E.004
10E.***	<p><u>Open Limit Adjustment</u></p> <p>It can be set between 0 to 60, the default value is 4.</p>	10E.004
11E.***	<p><u>No-vehicle Automatic Closing Time</u></p> <p>Set the time to automatically close the boom arm after successful verification but no vehicle passes, the larger the number, the longer it takes to close the boom arm. If the "Boom Arm Opening Memory" function is turned on, the gate will not be closed even after the unmanned time when the button "Open" is pressed. The Boom Arm Opening Memory function takes priority. It can be set between 5s and 60s, the default value is 0. When set to "0", this function is turned off.</p>	11E.000

12E.***	<p><u>Boom Arm Opening Memory</u></p> <ul style="list-style-type: none"> ● 12E.000: Close ● 12E.001: Open <p>When more than two legal access signals are given at the same time (including the same direction and the opposite direction), the system will remember all pass requests and complete each pass in turn.</p> <p>Memory opening is only available for use with external switch buttons and ground sensors.</p>	12E.000
13E.***	<p><u>Motor Forward and Reverse Rotation</u></p> <ul style="list-style-type: none"> ● 13E.000: Forward ● 13E.001: Reverse <p>When restoring the factory settings, this parameter will not be restored to the default value.</p>	13E.000
14E.***	<p><u>Reset</u></p> <ul style="list-style-type: none"> ● 14E.000: -Normal ● 14E.001: Reset ● 14E.002: Restore Bluetooth initial password: 12345678 <p>Select [14E.001] will restore the default factory setting.</p>	14E.000

15*.***	<p><u>Remote Control Pairing</u></p> <ul style="list-style-type: none"> ● 150.***: Normal ● 151.***: Add ● 152.***: Clear <p>Currently, it supports a maximum of 500 remote controls.</p> <p>Note: The third digit is adjusted by pressing [+/-] to add or clear remote control.</p> <p>In normal mode, the last three digits shows the number of remotes that have been paired with the current device.</p> <p>When restoring the factory settings, the remote control will not be cleared if remote control type has not changed.</p>	150.000
16E.***	<p><u>RS485 Address</u></p> <p>The valid value is 0 to 250.</p>	16E.000
17E.***	<p><u>Ground Sense Delay Time Setting</u></p> <p>Set the ground sense delay time by pressing [+/-] button, the larger the number set, the longer the delay time, the valid value is 0 to 251.</p>	17E.000
18E.***	<p><u>Self-test Mode</u></p> <ul style="list-style-type: none"> ● 18E.000: Automatic self-test (After power on, the device automatically performs self-test.) ● 18E.001: Manual self-test (It requires manual opening and closing of the barrier gate for self check.) 	18E.000

19E.***	<p><u>Buzzer Mode</u></p> <ul style="list-style-type: none"> ● 19E.000: Old mainboard ● 19E.001: New mainboard <p>When the buzzer mode setting does not match the mainboard, the device will beep continuously under normal circumstances.</p> <p>When restoring the factory settings, this parameter will not be restored to the default value.</p>	19E.001
20E.***	<p><u>Motor Type</u></p> <ul style="list-style-type: none"> ● 20E.000: Forward ● 20E.001: Reverse <p>When the motor type is incorrect, the buzzer makes an sound alarm, and the digital display will show: E*0.001.</p>	20E.000
21E.***	<p><u>Power-off Open Mode</u></p> <ul style="list-style-type: none"> ● 21E.000: Disable ● 21E.001: Enable 	21E.001
22E.***	<p><u>Open/Close Limit LED State</u></p> <ul style="list-style-type: none"> ● 22E.000: Open limit green light breathing, Close limit red light breathing ● 22E.001: Open limit green light always on, Close limit red light always on ● 22E.002: Open limit green light flashes, Close limit red light breathing 	22E.000
23E.***	<p><u>Open/Close LED State</u></p> <ul style="list-style-type: none"> ● 23E.000: The red light flashes during the whole process of opening and closing the boom arm. ● 23E.001: The red light is always on during the whole process of opening and closing the boom arm. 	23E.000

24E.***	<p><u>Remote Control Type</u></p> <ul style="list-style-type: none"> ● 24E.000: 433MHz frequency ● 24E.001: 430MHz frequency <p>When the remote control type changes, the remote control will be cleared.</p>	24E.000
25E.***	<p><u>Gate Opening and Ground Sensing Interface Switch</u></p> <ul style="list-style-type: none"> ● 25E.000: Normal interface status ● 25E.001: Switch gate opening and ground sensing signal interfaces <p>When this is set to "25E.001", the "IR / FIRE / DET / STOP / CLOSE / OPEN" interface is disabled, and the gate opening and ground sensing signal interfaces need to be connected to "IN2" and "IN1".</p> <p>When the old mainboard experiences signal interference and automatically opens or cannot close after opening, change this item to "25E.001".</p>	25E.000
26E.***	<p><u>Bluetooth/Wi-Fi Mode</u></p> <ul style="list-style-type: none"> ● 26E.000: Bluetooth Mode (Enable) ● 26E.001: Bluetooth Mode (Disable) ● 26E.002: Wi-Fi Mode <p>Switching Bluetooth mode and Wi-Fi mode will automatically restart the device.</p> <p>When restoring the factory settings, this parameter will not be restored to the default value.</p>	26E.000


8.3 Error Code

Error Code	Description	Solve
EL0001	Power-on Self-test failure, Hall limit detection error	Check if the boom is in a balanced state at 30 to 60 degrees; Check the 20E parameter.
EL0002	Hall limit detection error	Check the motor wiring or replace the mainboard.
EL0003	Unable to detect motor or Hall error	Check if the motor type is set incorrectly, if the motor wiring has poor contact, and if the motor is in good condition.
EL0004	Run timeout, motor rotates slowly	Check if it is a movement malfunction, unplug the power cord and motor cord, restart the machine, and shake the boom by hand to see if there is too much resistance.
EL0005	Caused by unstable 24V voltage output from the power supply	
EL0008	After closing to the limit, the boom was illegally lifted for a long time by human intervention	Release the boom lifting action and restart to open and close the barrier gate again until the device is in a normal state.
EL016	Tamper alarm	Release alarm signal.
EL032	Electric Motor Shaft Lock Protection failure	Check if there are any objects blocking the opening and closing of the barrier gate; Check if the boom is in a balanced state at 30 to 60 degrees; Check and adjust the 08E parameter.

8.4 Remote Control Pairing and Unpairing


8.4.1 Pairing

Long press **[Menu/save]**, then press **[Stop/▼]** flip down to **[15*.***]**. Press **[+/-]** to set the parameter value to **"151.***"**, and then press any button on the remote control until you hear a beep sound from the Mainboard, it means the pairing is successful, and then press **[Menu/save]** exit the menu.



8.4.2 Unpairing


Long press **[Menu/save]**, then press **[Stop/▼]** flip down to **[15*.***]**. Press **[+/-]** to set the parameter value to **"152.***"**. Press **[Menu/save]** to save the setting and that all the remote controls have been deleted.



8.5 Set Delay for Automatic Closing after Opening the


Boom Arm

Long press the **[Menu/save]** button, then press **[Stop/▼]** flip down to **[11E.***]** parameter, and then press the **[+/-]** to set the delay value as per the requirements. Finally, press **[Menu/save]** to exit the menu. For example, if it is set to **"11E.007"**, the device will automatically close after 7 seconds after opening the barrier gate.



9 Boom Arm Adjustments

9.1 Dimensions




9.2 Horizontal and Vertical Angle Adjustment of Boom

Arm (Mechanical Adjustment)

Note: The horizontal and vertical angles of the boom arm have been adjusted before leaving the factory. Please do not adjust them without the guidance of professionals to avoid mechanical damage.


1. Adjust the horizontal position of the boom arm

The connecting boom crank will be an overlapping structure, with the connecting boom arm's two rotation points coincident with the reducer's output shaft at three points and a line. The boom arm is in this position horizontally. If the boom arm is not level or inclined at this time, unscrew the two rocker (rocker-arm) screws, turn the boom arm to the level, and tighten the screws.




2. Adjust the vertical position of the boom arm (adjusted by mechanical structure)

The connecting boom arm crank is in an unfolded shape, and the connecting boom arm's two rotation points and the reducer's output shaft are in an unfolded 3-point line. This is the boom arm's vertical position. If the boom arm is not in the vertical position and is inclined, unscrew the two screws on the rocker (rocker-arm), rotate the boom arm to the vertical, and tighten the screws.



9.3 Direction Interchange of the Boom Arm


The operation steps are as follows:



1. Before operation, please turn off the power. Remove the spring, spring hanging arm and boom.
2. Change the direction of the Spindle Connecting Arm and linkage Arm.
3. Turn the Limited Block to the other direction.
4. After the mechanical operation, you need to set the movement parameter 13E Core Component Position on the motherboard, such as changing from L to R, the value of this parameter should be set from 1 to 0, or set the direction of the movement on the app.

9.4 Spring Adjustment

If the boom arm shakes when it rises, you can adjust the spring loosely, and if the boom arm shakes when it falls, you can adjust the spring tightly.



Note:

- 1) When the barrier boom is at 45°, it is the best balance.
- 2) The spring wire diameter is adapted to different boom lengths: 3m boom with $\phi 4.5\text{mm}$; 4.5m boom with $\phi 5.5\text{mm}$; 6m boom with $\phi 6.5\text{mm}$. (If the boom is too short i.e., less than 2m, do not install the spring).

10 Product Packing List

Material	Quantity
Chassis Explosion Screw M12X140	4
Keys	2
Barrier Boom	1
Boom Pressure Plate	1
Chassis Pressure Plate	2
Wireless Remote	2
Barrier Boom hexagon bolt M10X70	2
Machine	1
User manual	1

11 Troubleshooting

- ❖ **Description:** The Power Supply has a 24V output, but the mainboard power indicator does not light up.

Cause

1. 24V output wiring might be reversed
2. The mainboard might work abnormally
3. Loose wiring

Solution

1. Swap the DC output wiring
2. Replace the Mainboard
3. Tighten the wiring

- ❖ **Description:** The AC input is normal, but the power indicator is off.

Cause

1. The power fuse might be blown
2. Abnormal power supply
3. Loose wiring

Solution

1. Replace the fuse
2. Replace the power supply
3. Tighten the wiring

- ❖ **Description:** The power indicator is on, the landing boom indicator is normal, and the motor is not running.

Cause

1. The motor wiring might be wrongly connected, or the wiring is loose
2. The internal encoder of the motor may work abnormally
3. The motor stroke limit exceeds the position

Solution

1. Check the wiring according to the wiring diagram, and tighten the wiring if required
2. Replace the motor
3. Re-adjust the motor limit parameters

- ❖ **Description:** The remote-control buttons do not respond.

Cause:

1. The remote-control battery is completely discharged
2. There must be a signal interference with the same frequency and there might be some obstacles too nearby
3. The remote-control frequency is not matched, or the receiver is damaged

Solution:

1. Replace the battery
2. Use manual button control

3. Use in open areas
4. Replace the remote control to re-match or replace the receiver

❖ **Description:** When the boom is closed halfway, it bounces back to the open state.

Cause:

1. The barrier boom might not be installed
2. The spring is too tight, or the length of the barrier boom is changed, and the spring is not properly adjusted

Solution:

1. Install the barrier boom
2. Adjust the spring according to the length of the barrier boom

12 Safety Precautions

- It is strictly forbidden to hit the product with hard objects.
- When using, please handle with care to avoid strong collision with hard objects.
- Do not spill water or corrosive liquids on the surface of the product.
- If smoke or a peculiar smell comes from the product, disconnect the power immediately.

Note: If the product works abnormally, please contact the dealer in time. Please do not try to repair it by yourself. If you handle it without authorization, the company is not responsible for any damage.

13 Transportation and Storage

- When loading and unloading the product, handle it with care.
- During transportation and storage, place it in a dry and corrosive-free environment. The product should be protected from moisture, rain, sun, and corrosion.

14 Warranty

This product promises a warranty period of 2 years. Upon normal use of the product, damages are covered by the warranty. However, damages caused by the following conditions are not covered by the warranty.

- Damages caused by incorrect operation and violation of operating procedures.
- Damages caused by repairing the product without authorization.
- Abnormalities and damages caused by extremely harsh operating conditions and operating environment beyond the machine's ability to withstand.
- Damages caused by irresistible factors (such as earthquake, tsunami, typhoon).

KTeco Biometrics India Pvt Ltd.

B-1, Khata No. 31, Devasandra Industrial Estate, Whitefield Main Road,
Beside Phoenix mall, Mahadevapura, Bengaluru-560048, Karnataka, India.

Phone : 080 6828 1342

Mail : sales@zkteco.in

Website : www.zkteco.in

