

User Manual

InBioPC Series

Date: May 2025

Doc Version: 1.0

English

Thank you for choosing our product. Please read the instructions carefully before operation. Follow these instructions to ensure that the product is functioning properly. The images shown in this manual are for illustrative purposes only.



For further details, please visit our Company's website
www.zkteco.in.

Copyright © 2025 ZKTECO CO., LTD. All rights reserved.

Without the prior written consent of ZKTeco, no portion of this manual can be copied or forwarded in any way or form. All parts of this manual belong to ZKTeco and its subsidiaries (hereinafter the "Company" or "ZKTeco").

Trademark

ZKTeco is a registered trademark of ZKTeco. Other trademarks involved in this manual are owned by their respective owners.

Disclaimer

This manual contains information on the operation and maintenance of the ZKTeco equipment. The copyright in all the documents, drawings, etc. in relation to the ZKTeco supplied equipment vests in and is the property of ZKTeco. The contents hereof should not be used or shared by the receiver with any third party without express written permission of ZKTeco.

The contents of this manual must be read as a whole before starting the operation and maintenance of the supplied equipment. If any of the content(s) of the manual seems unclear or incomplete, please contact ZKTeco before starting the operation and maintenance of the said equipment.

It is an essential pre-requisite for the satisfactory operation and maintenance that the operating and maintenance personnel are fully familiar with the design and that the said personnel have received thorough training in operating and maintaining the machine/unit/equipment. It is further essential for the safe operation of the machine/unit/equipment that personnel has read, understood and followed the safety instructions contained in the manual.

In case of any conflict between terms and conditions of this manual and the contract specifications, drawings, instruction sheets or any other contract-related documents, the contract conditions/documents shall prevail. The contract specific conditions/documents shall apply in priority.

ZKTeco offers no warranty, guarantee or representation regarding the completeness of any information contained in this manual or any of the amendments made thereto. ZKTeco does not extend the warranty of any kind, including, without limitation, any warranty of design, merchantability or fitness for a particular purpose.

ZKTeco does not assume responsibility for any errors or omissions in the information or documents which are referenced by or linked to this manual. The entire risk as to the results and performance obtained from using the information is assumed by the user.

ZKTeco in no event shall be liable to the user or any third party for any incidental, consequential, indirect, special, or exemplary damages, including, without limitation, loss of business, loss of profits, business interruption, loss of business information or any pecuniary loss, arising out of, in connection with, or

relating to the use of the information contained in or referenced by this manual, even if ZKTeco has been advised of the possibility of such damages.

This manual and the information contained therein may include technical, other inaccuracies or typographical errors. ZKTeco periodically changes the information herein which will be incorporated into new additions/amendments to the manual. ZKTeco reserves the right to add, delete, amend or modify the information contained in the manual from time to time in the form of circulars, letters, notes, etc. for better operation and safety of the machine/unit/equipment. The said additions or amendments are meant for improvement /better operations of the machine/unit/equipment and such amendments shall not give any right to claim any compensation or damages under any circumstances.

ZKTeco shall in no way be responsible (i) in case the machine/unit/equipment malfunctions due to any non-compliance of the instructions contained in this manual (ii) in case of operation of the machine/unit/equipment beyond the rate limits (iii) in case of operation of the machine and equipment in conditions different from the prescribed conditions of the manual.

The product will be updated from time to time without prior notice. The latest operation procedures and relevant documents are available on <http://www.zkteco.in>

If there is any issue related to the product, please contact us.

ZKTeco Biometrics India Pvt Ltd.

Address B-1, Khata No. 31, Devasandra Industrial Estate,
Whitefield Main Road, Beside Phoenix mall,
Mahadevapura, Bengaluru-560048, Karnataka, India.

Phone 80 6828 1342

For business related queries, please write to us at: sales@zkteco.in.

To know more about our global branches, visit www.zkteco.com.

About the Company

ZKTeco is one of the world's largest manufacturer of RFID and Biometric (Fingerprint, Facial, Finger-vein) readers. Product offerings include Access Control readers and panels, Near & Far-range Facial Recognition Cameras, Elevator/floor access controllers, Turnstiles, License Plate Recognition (LPR) gate controllers and Consumer products including battery-operated fingerprint and face-reader Door Locks. Our security solutions are multi-lingual and localized in over 18 different languages. At the ZKTeco state-of-the-art 700,000 square foot ISO9001-certified manufacturing facility, we control manufacturing, product design, component assembly, and logistics/shipping, all under one roof.

The founders of ZKTeco have been determined for independent research and development of biometric verification procedures and the productization of biometric verification SDK, which was initially widely applied in PC security and identity authentication fields. With the continuous enhancement of the development and plenty of market applications, the team has gradually constructed an identity authentication ecosystem and smart security ecosystem, which are based on biometric verification techniques. With years of experience in the industrialization of biometric verifications, ZKTeco was officially established in 2007 and now has been one of the globally leading enterprises in the biometric verification industry owning various patents and being selected as the National High-tech Enterprise for 6 consecutive years. Its products are protected by intellectual property rights.

About the Manual

This manual introduces the operations of the **InBioPC400/InBioPC800**.

All figures displayed are for illustration purposes only. Figures in this manual may not be exactly consistent with the actual products.

Features and parameters with ★ are not available in all devices.

Document Conventions

Conventions used in this manual are listed below:

GUI Conventions

For Software	
Convention	Description
Bold font	Used to identify software interface names e.g. OK , Confirm , Cancel .
>	Multi-level menus are separated by these brackets. For example, File > Create > Folder.
For Device	
Convention	Description
< >	Button or key names for devices. For example, press <OK>.
[]	Window names, menu items, data table, and field names are inside square brackets. For example, pop up the [New User] window.
/	Multi-level menus are separated by forwarding slashes. For example, [File/Create/Folder].

Symbols






Convention	Description
	This represents a note that needs to pay more attention to.
	The general information which helps in performing the operations faster.
	The information which is significant.
	Care taken to avoid danger or mistakes.
	The statement or event that warns of something or that serves as a cautionary example.

Table of Contents

1	SAFETY INSTRUCTIONS.....	7
1.1	Important Notes.....	7
1.2	Installation Cautions.....	8
2	OVERVIEW.....	10
2.1	Features.....	11
2.2	Technical Specifications.....	12
3	CONTROLLER TERMINAL DESCRIPTION.....	14
3.1	Description of the LEDs on the Controller Panel.....	14
3.2	Appearance and System Components.....	16
3.3	Wire Selection Instructions.....	18
4	DE10.....	19
4.1	Wire Selection Instructions.....	21
5	INSTALLATION.....	22
6	ACCESS CONTROLLER WIRING.....	24
6.1	Power Supply Connection.....	24
6.2	Computer Connection.....	24
6.3	DE10 Connection.....	25
6.4	Auxiliary Outputs Connection.....	25
6.5	Auxiliary Inputs Connection.....	25
6.6	Alarm Connection.....	26
6.7	Fire Protection Input Interface Connection.....	27
7	DE10 WIRING.....	28
7.1	Reader Connection.....	28
7.1.1	Wiegand Reader Connection.....	28
7.1.2	Connecting the RS485 Reader.....	28
7.2	Connecting the Sensor.....	29
7.3	Connecting the Exit Button.....	29
7.4	Auxiliary Input Connection.....	30
7.5	Auxiliary Output Connection.....	31
7.6	Tamper Switch Connection.....	31
7.7	Lock Connection.....	31
8	ACCESS CONTROL SYSTEM.....	33
9	LOGIN TO WEBSERVER.....	34
9.1	PC.....	34
9.2	Phone.....	38
10	ZKBIO CVSECURITY INTEGRATION.....	39

10.1 Add the Device	39
10.2 Door	41
10.3 Reader	41
10.4 Auxiliary Input	42
10.5 Auxiliary Output	43
10.6 Event Type	44
10.7 Real-Time Monitoring	45
10.8 Alarm Monitoring	45
10.9 Interlock	46
10.10 Linkage	46
10.11 Anti-Passback	47
APPENDIX 1	48
Privacy Policy	48
Eco-friendly Operation	51

1 Safety Instructions

1.1 Important Notes

1. Before operating the device, please read and strictly follow all security and operation instructions. Please keep the instructions in good condition for future reference.
2. Please use the accessories recommended by the manufacturer or delivered together with the product. Any other related product is not recommended to be used as the alarm or monitoring system (cameras, infrared detectors, smoke detectors, etc.). The alarm or monitoring system should comply with the local applicable fire-prevention and security standards.
3. Do not place this device on any unstable table, tripod mount, subterminal or base to prevent the device from falling and damages, and more undesirably causing severe personal injuries. Therefore, it is important to install the device as instructed by the manufacturer.
4. All peripheral devices must be grounded.
5. No external connection wires can be exposed. All connections and idle wire ends must be wrapped with insulating tapes to prevent accidental contact with exposed wires from damaging the device.
6. Do not attempt to carry out unauthorized repair of the device. Disassembly or detachment is likely to cause electric shock or other physical problems. All repair should be done by qualified repair personnel.
7. In any of the following cases, disconnect the power supply from the device first and notify qualified repair personnel for repair:
 - The power cord or connector is damaged;
 - Liquid leaks into or any objects fall into the device;
 - The device has got wet or exposed to bad weather (rain, snow, etc.);
 - If the device cannot work normally even though it is operated as instructed;
 - The device falls down or its performance changes obviously.
8. If it is necessary to replace a component, the repair personnel must use only the substitutes specified by the manufacturer.
9. After the device is repaired, the repair personnel needs to conduct security inspection to ensure the device works normally.
10. Operate the device with only the type of power supply indicated on the label. Contact the operator for any uncertainty about the type of power supply.



Violation of any of the following cautions may result in personal injury or device malfunctions. We assume no responsibility for any damage caused by mishandling that is beyond normal usage defined in this product manual.

- Before installation, switch off the external circuit (that supplies power to the system).
- Before connecting the device to power supply, ensure the output voltage is within the specified range.
- Never connect the product to the power before completion of installation.

1.2 Installation Cautions

1. Network cable selection must be Super Category 5 network cable oxygen-free copper material above specifications, core nominal diameter 0.5mm. 100 meters of single wire resistance is less than 10 ohms. Try to choose a higher specification network cable (such as Category 6 oxygen-free copper material), reserve enough margin to meet the maximum load requirements.
2. All wiring must be sleeved, optional PVC pipe and galvanized pipe, to avoid mice bite off the line caused by failure. Although the controller has a good anti-static, lightning, leakage-proof design, please make sure that the controller chassis and AC ground connection is perfect, and the AC ground is truly grounded.
3. It is recommended not to plug and unplug connection terminals frequently when the system is energized. Be sure to unplug the connection terminals before starting any relevant welding job.
4. Do not detach or replace any control panel chip without permission because unprofessional operation may cause damage to the control panel.
5. It is recommended not to connect any other auxiliary devices without permission. All non-routine operations must be confirmed with our engineers in advance.
6. A control panel should not share one power socket with any other large-current devices.
7. It is preferable to install card readers and buttons at a height of 55 inches to 59 inches (1.4m to 1.5m) above the ground, subject to proper adjustment according to customers' usual practice.
8. The device is recommended to be installed in an easy-to-maintain location such as a server room or weak well.
9. The exposed part of any connection terminal is strongly recommended not be longer than 0.16 inches (4mm). Professional clamping tools may be used to avoid short-circuit or communication failure resulting from accidental contact with excessive exposed wires.
10. If you need to keep a record of access control events, periodically export the data from the controller.
11. Prepared countermeasures against unexpected power failure, like selecting power supply with UPS.

12. In order to prevent the self-induced electromotive force generated by the electric lock at the moment of switching on and off from affecting the access control system, it is necessary to connect a diode in parallel with the electric lock (please use the FR107 diode supplied with the system) to release the self-induced electromotive force generated at the moment of switching on and off of the electric lock during the wiring of the access control system on-site application.
13. It is recommended to use the power supply delivered with the system as the control panel power supply.
14. In a place with strong magnetic interference, galvanized steel pipes or shielded cables are recommended, and proper grounding is required.

2 Overview

The InBioPC Main Controller is the pinnacle of access control technology, offering seamless integration with DE-10 Door Units and supporting up to 4/8 access points. Engineered for high-speed TCP/IP communication, it ensures efficient and reliable data transfer. The onboard webserver, accessible via Wi-Fi, simplifies system configuration, providing unparalleled ease of use. Compliant with power over Ethernet (PoE IEEE802.3 and PSE@30W) standards, the InBioPC can power up to 4/8 DE-10 Door Units, delivering both performance and convenience.

This advanced controller boasts a suite of sophisticated access control functions and supports dynamic QR code generation through the ZKBio CVSecurity Mobile Applications, enhancing security and user experience. With support for InBioPC offers versatile authentication methods to meet diverse security needs. Its compatibility with the ZKTeco A&C push protocol ensures seamless communication with ZKBio CVSecurity software.

Operating within a wide voltage input range of AC 100V~240V, the InBioPC is designed for global deployment. It incorporates high-security data encryption methods, including HTTP / HTTPS, SSH, AES256, and TLS 2.0, safeguarding sensitive information. Supporting both Wiegand readers (formats: W26 / W34 / W66) and RS485 card readers (protocol: ZKTeco RS-485), it provides flexible connectivity options.

Furthermore, the InBioPC is designed in a standard 1U server rack size, ensuring compatibility with standard server rack installations. This makes it an ideal choice for organizations looking to deploy a robust, scalable, and secure access control solution.



InBioPC-400



InBioPC-800

2.1 Features

- Seamlessly integrates with DE-10 Door Units, supporting up to 4/8 access points.
- Supports high-speed TCP/IP communication for efficient data transfer.
- An embedded onboard webserver is available for system configuration and is accessible via Wi-Fi.
- Complies with IEEE 802.3 at PoE and PSE@30W standards to power up to 4/8 DE-10 Door Units.
- Equipped with advanced access control functions for enhanced security.
- Supports dynamic QR code generation with ZKBio CVSecurity Mobile Applications.
- Supports multiple credential options, including biometrics, RFID, and password.
- Compatible with the A&C push protocol.
- Operates with a wide voltage input range of AC 100V~240V.
- Supports high-security data encryption methods such as HTTP / HTTPS, SSH, AES256, and TLS 2.0.
- Supports Wiegand readers (formats: W26 / W34 / W66) and RS485 card readers (protocol: ZKTeco RS-485)
- Designed in standard 1U server rack size to be compatible with standard server rack installation.

2.2 Technical Specifications

Model	InBioPC-400	InBioPC-800
Onboard Visual Indicator	POWER (RED): ON - Power Normal, OFF - No Power; RUN (GREEN): Slow Flashing - Normal Use, Flashing - Host not connected, OFF - No Power; LAN (GREEN): Steady on - No data interaction, Flashing - Data in Interaction, OFF - Network Connection Abnormal; FIRE (RED): Flashing - In Fire Alarm, OFF - No Fire Alarm; AUX IN (RED): Flashing - In Alarm, OFF - No Alarm; DOOR (GREEN): Steady ON - Door Closed, Flashing - Door Open, OFF - Lock Offline	
Operation System	Linux	
Hardware	CPU: Dual Core@1.0GHz RAM: 128MB; ROM: 256MB	
Authentication method	Card / Password / Fingerprint / QR code	
Access Point Capacity	Onboard Access Point: 0 Max Access Point: 4 (with DE10 Door Unit)	Onboard Access Point: 0 Max Access Point: 8 (with DE10 Door Unit)
Fingerprint Template Capacity	4,000 (1:N) (Standard)	
Card Capacity	40,000 (1:N) (Standard)	
QR Code Capacity	40,000 (QR Code and Dynamic QR Code)	
User Capacity	40,000	
Transaction Capacity	200,000 (Standard)	
Number of Inputs	1*AUX Inputs, 1*FIRE	

Number of Outputs	1*Form C Relay for Aux Output 1*Form C Relay for Alarm	
Supported Biometric Algorithm	ZKFingerprint V10.0	
Max. Card Length	Supports up to 66 bits Card Length	
QR Code	Dynamic QR codes on the ZKBio CVSecurity mobile application QR code	
Communication	TCP/IP*1 Wi-Fi (IEEE802.11b/g/n/, 1T1R @ 2.4 GHz) (Wi-Fi only for webserver access)	
Standard Functions	Webserver, Up to 14-digit User ID, Access Levels, Access Groups, Holidays, Anti-passback, Anti-tailgating, Linkage, Global Linkage, Multiple Verification Methods	
Verification Speed	less than 0.3 sec (Fingerprint)	
Power Supply	Power Input: AC 100V~240V Power Output: POE (IEEE802.3at PSE@30W output) *4	Power Input: AC 100V~240V Power Output: POE (IEEE802.3at PSE@30W output) *8
Operating Temperature	0°C to 45°C	
Operating Humidity	20% to 80% RH (Non-condensing)	
Dimensions	440mm*180mm*45mm (L*W*H) (Standard 1U Server Rack Size)	440mm*180mm*45mm (L*W*H) (Standard 1U Server Rack Size)
Gross Weight	2.725Kg	2.825Kg
Net Weight	2.079Kg	2.179Kg
Supported Software	ZKBio CVSecurity	
Installation	Supported Rack-mount (Compatible with Standard Server Rack) / Wall-mount / Desktop	
Housing Material	SGCC	

Certifications

ISO14001, ISO9001, CE, FCC, RoHS

3 Controller Terminal Description

3.1 Description of the LEDs on the Controller Panel

When the InBioPC series controller is powered on, under normal conditions, the POWER indicator (red) is always on, the RUN indicator (green) flashes (indicating a normal system), and none of the other lights are on. However, in the following cases:



Menu	Color	Description
POWER	Red	Red light always on (power supply normal power supply) Red light off (abnormal power supply)
RUN	Green	Green light flashes slowly (system normal) Green light flashes fast (firmware upgrade in progress) Green light off (dead)
LAN	Green	Green light always on (no data interaction) Green light flashing (with data interaction) Green light off (abnormal network connection)


FIRE	Red	<p>Red light flashing (with access to fire protection and receiving a short circuit signal)</p> <p>Red light off (have access to fire protection but not receiving short circuit signal)</p>
AUX IN	Red	<p>Red light blinking (there is access to the auxiliary input and receive a signal)</p> <p>Red light off (auxiliary input accessed but no signal received)</p>
AUX OUT	Red	<p>Red light blinking (there is access to the auxiliary output and output signal)</p> <p>Red light is off (auxiliary output is connected, but no signal is received)</p>

The indicators for the access control terminals are as follows:







Menu	Color	Description
DOOR	Green	<p>Green light always on (online status door sensor off/no door sensor)</p> <p>Green light flashing (online status door sensor open)</p> <p>Green light off (offline status)</p>

3.2 Appearance and System Components




Access Control Terminal:


No.	Description
<p>AUX OUT</p> 	<p>Auxiliary output, can be connected to alarm or doorbell, etc.</p> <p>Maximum switching voltage of the contact is 24VDC, maximum switching current is 1A.</p>
<p>AUX IN</p> 	<p>Auxiliary input, can be connected to infrared human body sensing detector, fire alarm or smoke detector, etc.</p> <p>Maximum input voltage 12VDC.</p>

<p>ALARM</p> 	<p>Alarm output for alarm connection</p> <p>Maximum switching voltage of the contact is 24VDC, maximum switching current is 1A.</p>
<p>FIRE</p> 	<p>Fire input, external fire button, trigger the fire button, all doors forced normally open</p> <p>Maximum input voltage 12VDC.</p>


Reset:


No.	Description
<p>RESET</p> 	<p>Use a pickup pin to poke the device long:</p> <ul style="list-style-type: none"> 0 < Firmware Upgrade ≤ 5s (Insert the USB flash drive with firmware before poking the device with the pickup pin for a long time) 5s < Reboot ≤ 10s 10s < Restore Factory Settings

USB:

No.	Description
	<p>Support plugging in a USB flash drive to upgrade the firmware.</p>

Ethernet Interface:


No.	Description
<p>LAN</p> 	<p>Connect a switch for network communication.</p>






<p>PoE 1.....8</p> 	<p>4 PoE interfaces (InBioPC-400), 8 PoE interfaces (InBioPC-800), through this network interface directly to the front-end DE10 power supply and data transmission.</p>
--	--

3.3 Wire Selection Instructions

Name	Specifications	Maximum Distance
Network Cable	<p>Network cable selection must be Super Category 5 network cable oxygen-free copper material above specifications, single wire 100 meters resistance is less than 10 ohms. Try to choose a higher specification of network cable (such as Category 6 oxygen-free copper material), reserve enough margin to meet the maximum load requirements.</p>	100m

4 DE10



Terminal	Description	
	PoE	<p>Interfaces with the InBioPC series intelligent identification access controller.</p> <p>Compliant with IEEE 802.3at standard, DE10 recommended total output current less than 1.5A to external loads, including VOUT output, 485 reader power output, Wiegand reader power output, electric lock output, auxiliary output and so on.</p>
	Auxiliary Output	<p>Connect to alarm or doorbell, etc.</p> <p>Maximum switching voltage of the contact is 24VDC, maximum switching current is 1A.</p>
	Auxiliary Input	<p>Connect infrared human body sensor detector or smoke detector, etc.</p> <p>Maximum input voltage 12VDC</p>
	Tamper Switch	<p>Timely notification to stop illegal dismantling of device.</p> <p>Maximum input voltage 12VDC.</p>
	Wiegand Reader (Reader Out)	<p>Maximum output voltage 12VDC, maximum output current 0.5A, maximum input voltage 12VDC</p>

<div> <div>12V</div> <div>GND</div> <div>WD0</div> <div>WD1</div> <div>GLED</div> <div>BEEP</div> <div>READER IN</div> </div>	Wiegand Reader (Reader In)	Maximum output voltage 12VDC, maximum output current 0.5A, maximum input voltage 12VDC
<div> <div>12V</div> <div>GND</div> <div>485B</div> <div>485A</div> <div>READER</div> </div>	RS485 Reader	Maximum output voltage 12VDC, maximum output current 0.5A, maximum input voltage 6VDC
<div> <div>IN+</div> <div>IN-</div> <div>BUT</div> </div>	Exit Button	Connection of door exit button Maximum input voltage 12VDC
<div> <div>IN+</div> <div>IN-</div> <div>SEN</div> </div>	Sensor	Connecting door sensor Maximum input voltage 12VDC
<div> <div>NO</div> <div>COM</div> <div>NC</div> <div>LOCK</div> </div>	Lock	Connecting door lock Maximum switching voltage of contacts 30VDC, maximum switching current 5A
<div> <div>12V</div> <div>CND</div> <div>VOUT</div> </div>	Power Output	12V power output from DE10 (connected to InBioPC series directly via PoE) Maximum output voltage 12VDC, maximum output current 1A


4.1 Wire Selection Instructions

Name	Specifications	Maximum Distance
Wiegand	Adopt 6-core communication shielded cable (RVVP 6*0.5mm ²) (usually 6-core, 8-core, 10-core, users can choose according to the need of the port), to reduce the interference during transmission	20m
Electric lock	4-core cable (RVV 4* 0.75mm ² , 2-core power, 2-core door magnet) is used to minimize the impact on other components during the operation of the electric lock	20m
Exit Button	Use of 2- or 4-core cable (RVV 2 * 0.5mm ²)	20m
RS485 Reader	4-core communication cable (RVVSP 2 * 2 * 0.5mm ²) is used	20m with controller power supply
Network Cable	Network cable selection must be Super Category 5 network cable oxygen-free copper material above specifications, core nominal diameter 0.5mm. 100 meters of single wire resistance is less than 10 ohms. Try to choose a higher specification network cable (such as Category 6 oxygen-free copper material), reserve enough margin to meet the maximum load requirements	100m

5 Installation


● Installation in Cabinet

1. Attach the Back Plate to the device as shown in the figure below.
2. Place the device in the cabinet and secure it with screws.



- **Wall Mount**


1. Attach the Back Plate to the appliance as shown in the figure below.
2. Secure the device to the wall with screws.



6 Access Controller Wiring

6.1 Power Supply Connection


Please use the power supply configured for the InBioPC series controller which is rated 100 - 240V, AC 50/60Hz.



Note: Before connecting the power supply, please make sure that the controller is well connected to the chassis ground and the AC ground is truly grounded.

6.2 Computer Connection


Connect the InBioPC series controller to the PC software via an Ethernet cable. The wiring is shown below:



Note: The default IP address of the primary NIC is 192.168.1.201.


6.3 DE10 Connection

The InBio PC series controller communicates with the DE10 door units via a single network cable that also provides Power over Ethernet (PoE IEEE 802.3at). The DE10 units then connect to readers, exit buttons, locks, and other peripheral devices, creating a streamlined architecture. This design significantly reduces installation complexity, minimizes connection errors, lowers installation costs, and simplifies maintenance by eliminating troublesome traditional wiring methods.



6.4 Auxiliary Outputs Connection


The InBioPC series provides 1 auxiliary output connector for connecting an audible and visual alarm. Upon receiving signals such as fire alarms or unauthorized intrusions, the alarm will emit audible alerts and visual signals.




6.5 Auxiliary Inputs Connection

The InBioPC series provides 1 auxiliary input port for connecting infrared body sensing detectors, fire alarms or smoke detectors etc.


● Infrared Human Body Sensor Detector



● Fire




● Smoke Detector




6.6 Alarm Connection

The alarm sounds when signals such as fire alarms or break-ins are received.



6.7 Fire Protection Input Interface Connection

When the fire protection input interface is short-circuited, all doors of the unit automatically enter the normally open state, the alarm, and the global linkage function (need to be turned on). When the equipment restarts, it does not affect the normal function of the fire fighting interface.




7 DE10 Wiring

7.1 Reader Connection

7.1.1 Wiegand Reader Connection

Taking the ProID103 reader as an example, after the InBioPC series is successfully connected to the DE10, connect the Wiegand interface between the DE10 and the ProID103.




Note:

1. One DE10 has two Wiegand reader interfaces, up to 2 Wiegand readers can be connected, and single door bidirectional can be set up.
2. The reader should be installed about 1.4m from the ground and 30 ~ 50mm from the door edge.

7.1.2 Connecting the RS485 Reader

1. Shielded twisted-pair cables, which are internationally recognized, must be used. The recommended type of shielded twisted-pair cable is RVVSP4*0.5. The use of shielded twisted-pair cable helps to reduce and eliminate the distributed capacitance between the two 485 communication lines as well as the common-mode interference generated around the communication lines.
2. 485A and 485B data lines must be twisted, DE10 GND, 485A, 485B were connected to the RS485 reader GND, 485A, 485B. wiring must be cloth multi-stranded shielded twisted-pair cable, multi-stranded for backup, shielding is for debugging when a special situation arises, twisted because of the 485 communication using the principle of differential mode communication, twisted anti-jamming of the best.




Note:

1. A DE10 has one RS485 reader interface and up to 2 RS485 readers can be connected, the RS485 address codes must be 1 and 2.
2. The reader should be installed about 1.4m from the ground and 30 ~ 50mm from the door edge frame.
3. When DE10 is not connected to the controller's PoE port which is set as Master-slave mode or DE10 is in factory default state without prior controller connection, validating any card, password, fingerprint, or QR code on externally connected readers will successfully unlock the door lock for 5 seconds, no access records will be saved. (The controller 's PoE port mode can be set on the Webserver)


7.2 Connecting the Sensor

Door sensor is used to sense the switching state of the door, the access controller can detect the door being opened illegally through the door sensor switch, and then the alarm will be output. In addition, after opening the door in more than a specified period of time did not close the door, the access controller will also prompt the alarm. It is recommended to choose two-core wire, wire diameter of 0.22 square millimeters or more. If there is no need to know the switching status of the door online and no need for the door to be left open for a long time alarm, break-in alarm and interlock and other functions, the door sensor may not be connected.



7.3 Connecting the Exit Button


The exit button is a switching device for opening the door installed inside the room, and the door can be opened when the exit button is closed. The exit button is fixed at about 1.4 meters from the ground, and it should be ensured that the position of the exit button is correct, without distortion, and the wiring is accurate and firm (pinch off the exposed end of the unused wires and wrap them with insulating tape). Be careful to prevent electro sensor interference (such as: lighting switches, computers, etc.). It is recommended to use two-core wires with a cross-section area of 0.3 mm² or more for the wires connecting the exit button to the controller.




7.4 Auxiliary Input Connection

The DE10 provides 1 auxiliary input port for connecting infrared body sensing detectors or smoke detectors etc.

● Infrared Human Body Sensor Detector




● Smoke Detector




7.5 Auxiliary Output Connection

The DE10 provides 1 auxiliary output connector for connecting an audible and visual alarm.




7.6 Tamper Switch Connection

The tamper signal of the DE10 is connected to the tamper switch of the cabinet.




7.7 Lock Connection

1. One DE10 supports the control of a number of door locks.
2. The system supports both Normally Opened Lock and Normally Closed Lock. The NO Lock (normally opened when powered) is connected with 'NO1' and 'COM' terminals, and the NC Lock (normally closed when powered) is connected with 'NC1' and 'COM' terminals.
3. In order to prevent the electric lock from generating self-induced electromotive force on the access control system at the moment of switching, it is necessary to connect a diode in parallel with the electric lock (please use the FR107 supplied with the system) to release the self-induced electromotive force during the wiring of the field application of the access control system.
4. The VOUT terminal of the DE10 can supply power to the electric lock, but the lock's current draw must be less than 800mA.



8 Access Control System

Please use the power supply configured for the InBioPC series controller which is rated 100 - 240V, AC 50/60Hz.





9 Login to WebServer


The device has a built-in WebServer, which supports setting device parameters and checking device status, etc. on PC and cell phone.


9.1 PC

1. After the device is connected to power and connected to the network, open a browser and log in to the WebServer by entering the address, which is the **https:// IP address**. For example: **https://192.168.1.201**.



2. Enter the WebServer account and password, the default account is: **admin** and the password is: **admin**.






Note: The system is the initial password, the user logs in or visits the home page, the system reminds to modify the password, modify the success of the need to re-login.


Status Information

In the opened WebServer page, click **[Home]** to view the status information of all peripheral devices connected to the device such as reader, auxiliary input, auxiliary output, network and door.



Device Information


Click **[Device Info]** to browse the basic information and time information of the device.



The screenshot shows the 'Device Info' page of the InBioPC800 web interface. The left sidebar contains links for Home, Device Info (selected), Network Configuration, and System Management. The main content area is titled 'Device Info' and contains two sections: 'Basic Info' and 'Time Info'. The 'Basic Info' section displays the Device Name (InBioPC800), Serial Number (QAQ4242200004), MAC Address (00:17:61:13:24:43), and Firmware Version (AC Ver 20.0.10 Jul 23 2024). The 'Time Info' section displays the NTP State (Close), NTP Server Address, Time Zone (UTC+0800), Device Time (2024-07-25 15:07:41), and Device Timing (Start Sync). A copyright notice at the bottom reads '© 2024 ZKTECO CO., LTD. All rights reserved.'

Network Configuration

Click **[Network Configuration] > [TCP/IP Setting]** to change the IP address of the device, and you need to log in again after changing the IP address.



The screenshot shows the 'Network Configuration' page of the InBioPC800 web interface. The left sidebar contains links for Home, Device Info, Network Configuration (selected), and System Management. The main content area is titled 'Network Configuration' and contains two tabs: 'TCP/IP Setting' (selected) and 'Service Setting'. The 'TCP/IP Setting' tab displays input fields for IP Address (192.168.1.201), Subnet Mask (255.255.255.0), Gateway Address (192.168.1.1), and DNS (8.8.8.8). A 'Save' button is located below the input fields. A copyright notice at the bottom reads '© 2024 ZKTECO CO., LTD. All rights reserved.'

Click **[Network Configuration] > [Service Setting]** to support devices to connect to the server, such as ZKBioCVSecurity.

The screenshot shows the 'Network Configuration' page with the 'Service Setting' tab selected. The left sidebar contains 'Home', 'Device Info', 'Network Configuration' (highlighted), and 'System Management'. The main content area has two tabs: 'TCP/IP Setting' and 'Service Setting'. Under 'Service Setting', there are four fields: 'Server Mode' (dropdown menu set to 'IP Mode'), 'Connection Method' (dropdown menu set to 'HTTPS'), 'IP Address' (text field with '192.168.1.50' and a refresh icon), and 'Port' (text field with '8088'). A green 'Save' button is at the bottom. A copyright notice '© 2024 ZKTECO CO., LTD. All rights reserved.' is at the bottom center.

System Management


Click **[System Management]** to support setting device PoE port mode, setting Wi-Fi hotspot and reboot/restore factory settings/device upgrade.

The screenshot shows the 'System Management' page with the 'Port Setting' tab selected. The left sidebar contains 'Home', 'Device Info', 'Network Configuration', and 'System Management' (highlighted). The main content area has five tabs: 'Port Setting' (highlighted), 'Hotspot Setting', 'System Maintenance', 'POE Status', and 'Network Detection-PING'. Under 'Port Setting', there are eight 'POE' entries (POE-1 to POE-8), each with a dropdown menu. A dropdown menu is open for POE-2, showing 'Master-slave mode' (highlighted) and 'Switch mode'. A green 'Save' button is at the bottom. A note at the bottom states: 'The switch of network port mode requires a restart of the changed network port to take effect, which will cause the PoE power supply and network to be disconnected for a few seconds before automatically recovering!'.

Note: The PoE port can be set as Main-sub mode or Switch mode. The switch of network port mode requires a restart of the changed network port to take effect which will cause the PoE power supply and network to be disconnected for a few seconds before automatically recovering!

9.2 Phone

There is no need to enter the IP address of the device on the cell phone. After the device is connected to the power supply and the network, the cell phone should be close to the device, find the hotspot of the device (by default, it is the serial number of the device), and then click on it and enter the WebServer account and password in the pop-up login interface.




10 ZKBio CVSecurity Integration

The device connects to ZKBio CVSecurity by setting up ZKBio CVSecurity-related information in [Web Configuration] > [Server Settings] of the WebServer (no need to set up if the device and the server are in the same network segment). The device can add devices, set up access control rules, set up global anti-passback, linkage, interlocking, and other access control operations on ZKBio CVSecurity.

10.1 Add the Device

1. Open ZKBio CVSecurity and log in to ZKBio CVSecurity by entering your account number and password.



2. In the **Access Control** module, select **[Device] > [Access Control Device]**.
3. On the device interface, click the **[Search]** button to pop up a search box.
4. Click **[Start Search]** in the search box to display the **access control devices** that can be added, as shown in the figure below.

Search

No device found? [Download Search Tools to Local Disk](#)

Total Progress 100%

Searched devices count:1
Number of devices added:1

IP Address Device Type Serial Number

IP Address	MAC Address	Subnet Mask	Gateway Add...	Serial Number	Device Type	Set Server	Operations
192.168.134.168		255.255.255.0	192.168.134.254	CN3M212460001	TDB08M-TI/M		This device has been

The current system communication port is 8088, please make sure the device is set correctly.

Close

- Optional: Modify the IP address of the **Access Control** device, click [**Modify IP Address**], the device will be restarted after modifying the IP address, and the IP address modification will be completed after the restart.
- For the searched access control devices, click the [**Add**] button in the operation bar to add the device.

New

Device Name*

Communication Type* ☒ TCP/IP ☐ RS485

IP Address*

Communication port*

Communication Password

Icon Type*

Control Panel Type

Area*

Add to Level

Clear Data in the Device when Adding ☐

[Clear Data in the Device when Adding] will delete data in the device (except event record), please use with caution!

OK Cancel

10.2 Door

1. In the **Access Control** module, select **[Devices]** > **[Door]**.
2. In the management interface of the door, click the **[Edit]** button in the door operation bar to pop up the door parameter setting box.
3. In the door parameter setting interface, fill in the corresponding parameters according to the addition requirements, as shown in figure below.

The screenshot shows the 'Edit' dialog box for door parameters. The dialog is titled 'Edit' and has a close button (X) in the top right corner. It contains two columns of settings. The left column includes: Device Name* (ZKT_Korea), Door Name* (ZKT_Korea-1), Verification Mode* (Automatic Identification), Operate Interval* (0 second(0-254)), Anti-Passback Duration of Entrance (0 minute(0-120)), Duress Password (Maximum 6 Bit Integer), Emergency Password (8 Bit Integer), and Disable Alarm Sounds (checkbox). The right column includes: Door Number* (1), Active Time Zone* (24-Hour Accessible), Lock Open Duration* (5 second(1-254)), Door Sensor Type* (None), Door Sensor Delay (second(1-254)), Passage Mode Time Zone (-----), Multi-Person Operation Interval* (10 second(5-60)), and a dropdown menu for 'The above settings are copied to'. At the bottom, there are OK and Cancel buttons.

10.3 Reader

1. In the **Access Control** module, choose **[Device]** > **[Reader]**.
2. In the Operation column of the corresponding Reader, click . The bind/unbind camera page is displayed.
3. On the Select Reader screen, set the Reader as required, as shown in figure below.

Binding/unbinding the camera

Channel Name Serial Number

Alternative

<input type="checkbox"/>	Channel Name	Owned Device	Serial Number
<input type="checkbox"/>	192.168.134.59	AS1700	21024127099SL8i

Selected(0)

<input type="checkbox"/>	Channel Name	Owned Device	Serial Number
--------------------------	--------------	--------------	---------------

>>
>
<
<<

No data

1-1 50 rows per page

OK Cancel

10.4 Auxiliary Input

- Click **[Access Device] > [Auxiliary Input]** on the Action Menu, to access below shown interface.
- Click on **[Name]** or **[Edit]** to modify the parameters as shown below:

ZKBio CVSecurity

Access Device

Device

I/O Board

Door

Reader

Auxiliary Input

Auxiliary Output

Event Type

Daylight Saving Time

Device Monitoring

Real-Time Monitoring

Alarm Monitoring

Map

Access / Access Device / Auxiliary Input

Name Device Name Printed Name

Refresh

Name	Device Name	Number	Printed Name	Bound camera	Owning Board	Remarks	Operations
Auxiliary Input-1	ZKT_Korea	1	IN1				<input type="button" value="Edit"/> <input type="button" value="Delete"/>

Edit

Device Name*

Number*

Name*

Printed Name*

Active Time Zone


Remarks

OK Cancel

- Click **[OK]** to save the name and remark and exit.

10.5 Auxiliary Output

1. Click **[Access Device] > [Auxiliary Output]** on the Action Menu to access the following interface:



2. Click **[Edit]** to modify the parameters.

The 'Edit' dialog box contains the following fields and values:

Field	Value
Device Name*	192.168.12.155
Number*	1
Name*	Auxiliary Output-1
Printed Name*	OUT1
Passage Mode Time Zone	-----
Remark	

At the bottom of the dialog are 'OK' and 'Cancel' buttons.

3. Click **[OK]** to save the name and remark and exit.

10.6 Event Type

1. Click **[Access Device]** > **[Event]** to access the following page:

Access / Access Device / Event Type

Event Name Event Number Event Level More

<input type="checkbox"/>	Event Name	Event Number	Event Level	Device Name	Serial Number	Operations
<input checked="" type="checkbox"/>	Normal_Verify_Open	0	Normal	ZKT_Korea	CL63202960014	<input type="button" value="✎"/>
<input type="checkbox"/>	Verify_During_Passage_Mode_T	1	Normal	ZKT_Korea	CL63202960014	<input type="button" value="✎"/>
<input type="checkbox"/>	First-Personnel_Open	2	Normal	ZKT_Korea	CL63202960014	<input type="button" value="✎"/>
<input type="checkbox"/>	Multi-Personnel_Open	3	Normal	ZKT_Korea	CL63202960014	<input type="button" value="✎"/>
<input type="checkbox"/>	Emergency_Password_Open	4	Normal	ZKT_Korea	CL63202960014	<input type="button" value="✎"/>
<input type="checkbox"/>	Open_during_Passage_Mode_T	5	Normal	ZKT_Korea	CL63202960014	<input type="button" value="✎"/>
<input type="checkbox"/>	Linkage_Event_Triggered	6	Normal	ZKT_Korea	CL63202960014	<input type="button" value="✎"/>
<input type="checkbox"/>	Cancel_Alarm	7	Normal	ZKT_Korea	CL63202960014	<input type="button" value="✎"/>

2. Click **[Edit]** or click the event type name to edit.

Edit

Device Name*

Event Number*

Event Level*


Event Name*

Event Sound ☒ Already Exists ☐ Upload

Copy the above settings to all devices ☐


10.7 Real-Time Monitoring

1. In the **Access Control** module, choose **[Access Control Device] > [Real-time Monitoring]**.
2. Check whether the icon status of the added device is online.




10.8 Alarm Monitoring

It will monitor the status and real-time events of doors under the access control panels in the system in real-time, including normal events and abnormal events.



10.9 Interlock


Set interlock control between two or more doors on the access controller device: To verify the opening of a door, ensure that all other doors interlocked with the door are closed; otherwise, the door cannot be opened. In the **Access Control** module, choose **[Access Control] > [Interlock]** and click **[New]**.



The 'New' dialog box for setting interlock control. It contains two fields: 'Device Name*' with a 'Click to select' button, and 'Interlock Rule*' with a dropdown menu showing '-----'. At the bottom are three buttons: 'Save and New' (green), 'OK' (green), and 'Cancel' (white).

10.10 Linkage


The use method and scenario of linkage are flexible. After a specific event is triggered by an input point in the **Access Control** system, a linkage action will be generated at the specified output point to control events such as verification opening, alarm and abnormality in the system. Add Settings for binding cameras to access control devices, input points, output points, and reader.



The 'Outgoing Mail Server Settings' dialog box. It contains a tab labeled 'Outgoing Mail Server Settings' and several input fields: 'Email Sending Server*' (with placeholder '(smtp.xxx.xxx)'), 'Port*' (with value '25'), 'Email Account*' (with placeholder '(xxx@xxx.xxx)'), 'Password*', and 'Sender Name'. There are checkboxes for 'SSL' and 'TLS'. A green 'Test Connection' button is located below the fields. At the bottom, there is a warning icon and the text 'Please complete the email verification.' and two buttons: 'OK' and 'Cancel'.

10.11 Anti-Passback

Some occasions require the personnel that brush card to verify, brush card to come in from a door must brush card to go out from another door, brush card record must enter a strict correspondence. This function can be used when users enable it in the settings. It is generally used in special units, scientific research, bank vaults and other occasions. In the **Access Control** module, choose **[Access Control] > [Anti-Passback]** and click **[New]**.



The screenshot shows a 'New' dialog box with a close button (X) in the top right corner. It contains two input fields: 'Device Name*' with a 'Click to select' button, and 'Anti-Passback Rule*' with a dropdown arrow. At the bottom, there are three buttons: 'Save and New' (green), 'OK' (green), and 'Cancel' (white).

For more detailed information on the use of the ZKBio CVSecurity, please refer to the *ZKBio CVSecurity User Manual*.

Appendix 1

Privacy Policy

Notice:

To help you better use the products and services of ZKTeco (hereinafter referred to as “we”, “our”, or “us”) a smart service provider, we consistently collect your personal information. Since we understand the importance of your personal information, we took your privacy sincerely and we have formulated this privacy policy to protect your personal information. We have listed the privacy policies below to precisely understand the data and privacy protection measures related to our smart products and services.

Before using our products and services, please read carefully and understand all the rules and provisions of this Privacy Policy. If you do not agree to the relevant agreement or any of its terms, you must stop using our products and services.

I. Collected Information

To ensure the normal product operation and help the service improvement, we will collect the information voluntarily provided by you or provided as authorized by you during registration and use or generated as a result of your use of services.

- 1. User Registration Information:** At your first registration, the feature template (**Fingerprint template/Face template/Palm template**) will be saved on the device according to the device type you have selected to verify the unique similarity between you and the User ID you have registered. You can optionally enter your Name and Code. The above information is necessary for you to use our products. If you do not provide such information, you cannot use some features of the product regularly.
- 2. Product information:** According to the product model and your granted permission when you install and use our services, the related information of the product on which our services are used will be collected when the product is connected to the software, including the Product Model, Firmware Version Number, Product Serial Number, and Product Capacity Information. **When you connect your product to the software, please carefully read the privacy policy for the specific software.**

II. Product Security and Management

- 1.** When you use our products for the first time, you shall set the Administrator privilege before performing specific operations. Otherwise, you will be frequently reminded to set the Administrator privilege when you enter the main menu interface. **If you still do not set the**

Administrator privilege after receiving the system prompt, you should be aware of the possible security risk (for example, the data may be manually modified).

2. All the functions of displaying the biometric information are disabled in our products by default. You can choose Menu > System Settings to set whether to display the biometric information. If you enable these functions, we assume that you are aware of the personal privacy security risks specified in the privacy policy.
3. Only your user ID is displayed by default. You can set whether to display other user verification information (such as Name, Department, Photo, etc.) under the Administrator privilege. **If you choose to display such information, we assume that you are aware of the potential security risks (for example, your photo will be displayed on the device interface).**
4. The camera function is disabled in our products by default. If you want to enable this function to take pictures of yourself for attendance recording or take pictures of strangers for access control, the product will enable the prompt tone of the camera. **Once you enable this function, we assume that you are aware of the potential security risks.**
5. All the data collected by our products is encrypted using the AES 256 algorithm. All the data uploaded by the Administrator to our products are automatically encrypted using the AES 256 algorithm and stored securely. If the Administrator downloads data from our products, we assume that you need to process the data and you have known the potential security risk. In such a case, you shall take the responsibility for storing the data. You shall know that some data cannot be downloaded for sake of data security.
6. All the personal information in our products can be queried, modified, or deleted. If you no longer use our products, please clear your personal data.

III. How We Handle Personal Information of Minors

Our products, website and services are mainly designed for adults. Without consent of parents or guardians, minors shall not create their own account. If you are a minor, it is recommended that you ask your parents or guardian to read this Policy carefully, and only use our services or information provided by us with consent of your parents or guardian.

We will only use or disclose personal information of minors collected with their parents' or guardians' consent if and to the extent that such use or disclosure is permitted by law or we have obtained their parents' or guardians' explicit consent, and such use or disclosure is for the purpose of protecting minors.

Upon noticing that we have collected personal information of minors without the prior consent from verifiable parents, we will delete such information as soon as possible.

IV. Others

You can visit https://www.zkteco.com/en/index/Index/privacy_protection.html to learn more about how we collect, use, and securely store your personal information. To keep pace with the rapid development of technology, adjustment of business operations, and to cope with customer needs, we will constantly deliberate and optimize our privacy protection measures and policies. Welcome to visit our official website at any time to learn our latest privacy policy.

Eco-friendly Operation



The product's "eco-friendly operational period" refers to the time during which this product will not discharge any toxic or hazardous substances when used in accordance with the prerequisites in this manual.

The eco-friendly operational period specified for this product does not include batteries or other components that are easily worn down and must be periodically replaced. The battery's eco-friendly operational period is 5 years.

Hazardous or Toxic substances and their quantities

Component Name	Hazardous/Toxic Substance/Element					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr6+)	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Chip Resistor	×	○	○	○	○	○
Chip Capacitor	×	○	○	○	○	○
Chip Inductor	×	○	○	○	○	○
Diode	×	○	○	○	○	○
ESD component	×	○	○	○	○	○
Buzzer	×	○	○	○	○	○
Adapter	×	○	○	○	○	○
Screws	○	○	○	×	○	○

This table is prepared in accordance with the provisions of SJ/T 11364.

○ indicates that the total amount of toxic content in all the homogeneous materials is below the limit as specified in GB/T 26572.

× indicates that the total amount of toxic content in all the homogeneous materials exceeds the limit as specified in GB/T 26572.

Note: 80% of this product's components are manufactured using non-toxic and eco-friendly materials. The components which contain toxins or harmful elements are included due to the current economic or technical limitations which prevent their replacement with non-toxic materials or elements.

ZKTeco Biometrics India Pvt Ltd.

B-1, Khata No. 31, Devasandra Industrial Estate, Whitefield Main Road,
Beside Phoenix mall, Mahadevapura, Bengaluru-560048, Karnataka, India.

Phone : 080 6828 1342

Mail : sales@zkteco.in

Website : www.zkteco.in

